


INSTRUCTION MANUAL

(For Analog Watch Without EL Light)

Thank you for purchasing our products. To ensure prolonged use and optimum performance please read this instruction manual carefully and familiarize yourself with the terms of warranty. We suggest that you keep this instruction manual at hand and refer to it whenever required.

HOW TO SET TIME:

1. Pull out the crown for a click, set the hands by turning the crown in either direction to the desired hour and minute time.
2. Push the crown to the normal position to start.



HOW TO REPLACE MOVEMENT BATTERY:

1. Remove the insulator on the movement, you will see movement battery SR626SW. Take out the dead battery.
2. Place new battery and close case back.
3. Adjust the hand at the correct time.

NOTE: Avoid short circuit or exposing the battery in fire.

TO PRESERVE THE QUALITY OF YOUR WATCH:

1. As this watch contains precise electronic components, it is suggested that the back cover be removed only by authorized person.
2. If the watch is used in water, or it is wet, wipe it thoroughly dry.
3. Should water or condensation appear in the watch, immediately open the case back and leave it air dry because water can corrode electronic parts inside the case.
4. Although the watch is designed to withstand shocks under normal use, it is inadequate to subject it to rough impact.
5. Clean the watch with a soft cloth or water. Never use chemical solution.
6. Avoid exposure the watch to chemicals such as gasoline, aero spray, paints etc, those chemical action will damage watch.
7. Avoid wearing the watch in electro magnetic condition, or put watch under strong light for too long.